




Ø19急停按钮 Emergency Stop Button

名称/外观 Product appearance	操作类型 Operation type	安装方法 Method	开关组合 Contact Configuration	触点 Contact	产品型号 Model	外壳材料 Crust Material
	推锁旋放式 Push-lock Turn-reset	拆装式 Combined Structure	1NO 1NC 2NO 2NC	单刀/1Pole	J19-811	不锈钢 Stainless steel
				双刀/2Pole	J19-812	
	推锁旋放式 Push-lock Turn-reset	拆装式 Combined Structure	1NO 1NC 2NO 2NC	单刀/1Pole	J19-A11	不锈钢 Stainless steel
				双刀/2Pole	J19-A12	

急停按钮



急停按钮

