





Ø30按钮开关 / Ø30 Pushbutton switches

名称/外观 Product appearance	带灯形式 Illuminated type	操作类别 Operation	触点 Contact	产品型号 Model	颜色 Color	额定电压 Rated Voltage
平头形/ Flush 	不带灯 Without LED	自复 Momentary	1NO	SD30-2110		
			1NC	SD30-2101		
			2NO	SD30-2120		
			2NC	SD30-2102		
			1NO+1NC	SD30-2111		
		自锁 Maintained	1NO	SD30-3110		
			1NC	SD30-3101		
			2NO	SD30-3120		
			2NC	SD30-3102		
			1NO+1NC	SD30-3111		
带灯平头形/ Flush with LED 	带灯 With LED	自复 Momentary	1NO	SD30-2710	K 黑色 / Black G 绿色 / Green R 红色 / Red B 蓝色 / Blue W 白色 / White Y 黄色 / Yellow	D:24VDC E:12VDC F:6.3VDC A1:110VAC A2:220VAC
			1NC	SD30-2701		
			2NO	SD30-2720		
			2NC	SD30-2702		
			1NO+1NC	SD30-2711		
		自锁 Maintained	1NO	SD30-3710		
			1NC	SD30-3701		
			2NO	SD30-3720		
			2NC	SD30-3702		
			1NO+1NC	SD30-3711		

平头按钮

