







Ø30选择开关 / Ø30 Selector Switches

名称/外观 Product appearance	带灯形式 Illuminated type	位数 Positions	操作类别 Operation	触点 Contact	产品型号 Model	额定电压 Rated Voltage
选择开关/ Selector Switches 	不 带 灯 Without LED		自复/Momentary	1NO	SD30-4110-0	
				1NC	SD30-4101-0	
				2NO	SD30-4120-0	
				2NC	SD30-4102-0	
				1NO+1NC	SD30-4111-0	
				1NO	SD30-4110-2	
		1NC	SD30-4101-2			
		2NO	SD30-4120-2			
		2NC	SD30-4102-2			
		1NO+1NC	SD30-4111-2			
		2NO	SD30-5120-3			
		2NC	SD30-5102-3			
1NO+1NC	SD30-5111-3					
带灯选择开关/Selector Switches with LED 	带 灯 With LED		自复/Momentary	1NO	SD30-4710-0	D:24VDC E:12VDC F:6.3VDC A1:110VAC A2:220VAC
				1NC	SD30-4701-0	
				2NO	SD30-4720-0	
				2NC	SD30-4702-0	
				1NO+1NC	SD30-4711-0	
				1NO	SD30-4710-2	
		1NC	SD30-4701-2			
		2NO	SD30-4720-2			
		2NC	SD30-4702-2			
		1NO+1NC	SD30-4711-2			
		2NO	SD30-5720-3			
		2NC	SD30-5702-3			
1NO+1NC	SD30-5711-3					

选择开关

